

PAN'N FLOOR PANEL™ KIT

USE AND CARE INSTRUCTIONS

ROUTINE CLEANING OF SHOWER FLOORS:

Floor panels' sanitary properties do not allow dirt, soap scum, bacteria or germs to penetrate. Routine cleaning with non-abrasive bathroom cleaner and a sponge will remove most dirt and stains.

FOR STUBBORN STAINS:

Using a burgundy or green-colored Scotch-Brite® pad, rub the stain with a scouring cleanser and water. Always rub in a circular motion. Then rinse and towel dry. Rub the entire floor surface occasionally with the Scotch-Brite® pad to maintain the finish.

DISINFECTING YOUR SHOWER FLOOR:

Wipe with diluted household bleach (1:1 water:bleach solution) to disinfect.

REMOVING CUTS AND SCRATCHES:

Gently sand with 180-grit (120 micron) or 220-grit (60 micron) fine sandpaper until the cut or scratch is removed. Restore finish by rubbing an abrasive cleanser in a circular motion using a burgundy-colored Scotch-Brite® pad; rub until the finish matches the adjacent surface.

PREVENTING DAMAGE:

Strong chemicals can cause damage to your floor panels surface if left in contact for a period of time. Solvents containing methylene chloride or acetone (nail polish remover), acid drain and toilet bowl cleaners, paint removers, contact adhesive solvent, rust removers, or lacquer thinners should be flushed with soapy water as quickly as possible, then rinsed thoroughly with clean water and towel dried.

Tile Redi, LLC is not affiliated with any of the third-party cleaning product brands identified in this material.

Scotch-Brite® is a registered trademark of 3M®.